





--







## 



A = NUCLEOSIDE REPLACEMENT

B = ATTACHMENT TO A BASE

C = ATTACHEMENT TO A RIBOSE

D = ATTACHMENT TO A PHOSPHATE

E = METALLOCENE POLYMER, ATTACHED TO A RIBOSE, PHOSPHATE, OR BASE

F = DENDRIMER STRUCTURE, ATTACHED VIA A RIBOSE, PHOSPHATE OR BASE

## FIG. 5A




FIG. 5B





FIG.\_5C





H = ATTACHMENT OF METALLOCENE POLYMERS


I = ATTACHMENT VIA DENDRIMER STRUCTURE


J = ATTACHMENT USING STANDARD LINKERS

## FIG.\_5D


























+

1

